

# Errata sheet

This Errata sheet is applied for the software version V108/109.

Please check following parameter carefully.  
Initial setting value was changed.

1. Page K-2, K-5

(Related model is only WP model of 500V)

“VLV/F171” default setting was changed. (VLV/F171=460      VLV/F171=400)

Title	Function	Adjustment range	Default setting
<i>υ L υ</i>	Base frequency voltage 1	50-330(240V class) 50-660(500V class)	230(240V class) 400(500V class)
<i>F 1 7 1</i>	Base frequency voltage 2	50-330(240V class) 50-660(500V class)	230(240V class) 400(500V class)

**CAUTION:**

When TYP=3 (initialization) is executed, “VLV/F171” are set to “460”.

In this case, please set parameters again as you need.

Please check power supply voltage and the following parameters.

<i>P t</i>	<i>F 3 0 7</i>	<i>υ L υ / F 1 7 1</i>
0 or 1	0 or 2	200V(240V class) 400V(500V class)
2 to 6	don't care	Please confirm and set the power supply voltage to parameters.
don't care	1 or 3	Please confirm and set the power supply voltage to parameters.

- End -